## **SERVICE & OPERATING MANUAL**Original Instructions

### **Certified Quality**

( (








Warren Rupp, Inc. A Unit of IDEX Corporation 800 N. Main St., Mansfield, Ohio 44902 USA Telephone (419) 524.8388 Fax (419) 522.7867 SANDPIPERPUMP.COM



©2025 Warren Rupp, Inc.

# **GH2M**Gas Duty - High Pressure Design Level 1



### **Safety Information**

#### **A** IMPORTANT



Read the safety warnings and instructions in this manual before pump installation and start-up. Failure to comply with the recommendations stated in this manual could damage the pump and void factory warranty.



When the pump is used for materials that tend to settle out or solidify, the pump should be flushed after each use to prevent damage. In freezing temperatures the pump should be completely drained between uses.

#### **A** CAUTION



Before pump operation, inspect all fasteners for loosening caused by gasket creep. Retighten loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



Nonmetallic pumps and plastic components are not UV stabilized. Ultraviolet radiation can damage these parts and negatively affect material properties. Do not expose to UV light for extended periods of time.



#### <u>WARNING</u>

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

#### RECYCLING

Many components of SANDPIPER® AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed.

#### WARNING



When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. Be certain that approved eye protection and protective clothing are worn at all times. Failure to follow these recommendations may result in serious injury or death.



Airborne particles and loud noise hazards. Wear eye and ear protection.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product that is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe containment.



Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers and other miscellaneous equipment must be properly grounded.



This pump is pressurized internally with air pressure during operation. Make certain that all fasteners and piping connections are in good condition and are reinstalled properly during reassembly.



Use safe practices when lifting

### **ATEX Pumps - Conditions For Safe Use**

- 1. Ambient temperature range is as specified in tables 1 to 3 on the next page (per Annex I of DEKRA 18ATEX0094X)
- ATEX compliant pumps are suitable for use in explosive atmospheres when the equipment is properly grounded in accordance with local electrical codes
- Non-Metallic ATEX Pumps only See Explanation of Pump Nomenclature / ATEX Details Page
   Conductive Polypropylene, conductive Acetal or conductive PVDF pumps are not to be installed in applications where the
   pumps may be subjected to oil, greases and hydraulic liquids.
- 4. The optionally provided solenoids shall be protected by a fuse corresponding to its rated current (max 3\*Irat according to EN 60127) or by a motor protecting switch with short circuit and thermal instantaneous tripping (set to the rated current) as short circuit protection. For solenoids with a very low rated current, a fuse with the lowest current value according to the indicated standard will be sufficient. The fuse may be accommodated in the associated supply unit or shall be separately arranged. The rated voltage of the fuse shall be equal or greater than the stated rated voltage of the solenoid. The breaking capacity of the fuse shall be as high as or higher than the maximum expected short circuit current at the location of the installation (usually 1500 A). The maximum permissible ripple is 20% for all dc solenoids.

  \*Not applicable for all pump models See Explanation of Pump Nomenclature / ATEX Details Page
- 5. When operating pumps equipped with non-conductive diaphragms that exceed the maximum permissible projected area, as defined in EN ISO 80079-36: 2016 section 6.7.5 table 8, the following protection methods must be applied
  - Equipment is always used to transfer electrically conductive fluids or
  - Explosive environment is prevented from entering the internal portions of the pump, i.e. dry running.
- 6. Pumps provided with the pulse output kit and used in the potentially explosive atmosphere caused by the presence of the combustible dust shall be installed in such a way that the pulse output kit is protected against impact \*Not applicable for all pump models See Explanation of Pump Nomenclature / ATEX Details Page



SANDPIPERPUMP.COM

### **Temperature Tables**

Table 1. Category 1 & Category 2 ATEX Rated Pumps

Ambient Temperature Range [°C]	Process Temperature Range [°C]¹	Temperature Class	Maximum Surface Tem- perature [°C]
	-20°C to +80°C	T5	T100°C
0000 10000	-20°C to +108°C	T4	T135°C
-20°C to +60°C	-20°C to + 160°C	Т3	T000%0
	-20°C to +177°C	(225°C) T2	T200°C

<sup>&</sup>lt;sup>1</sup>Per CSA standards ANSI LC6-2018 US & Canadian Technical Letter R14, G-Series Natural Gas Models are restricted to (-20°C to + 80°C) process temperature

Table 2. Category 2 ATEX Rated Pumps Equipped with Pulse Output Kit or Integral Solenoid:

Ambient Temperature	Process Temperature	Temperature	Maximum Sur-	Ор	tions
Range [°C]	Range [°C]	Class	face Temperature [°C]	Pulse Output Kit	Integral Solenoid
-20°C to +60°C	-20°C to +100°C	T5	T100	Х	
-20°C to +50°C	-20°C to +100°C	T5	T100		Х

<sup>&</sup>lt;sup>2</sup>ATEX Pulse output or Intergral Solenoid Not Available For All Pump Models See Explanation of Pump Nomenclature / ATEX Details Page

Table 3. Category M1 ATEX Rated Pumps for Mining

Ambient Temperature	Process Temperature	
Range [°C]	Range [°C]	
-20°C to +60°C	-20°C to +150°C	


<u>Note:</u> The ambient temperature range and the process temperature range should not exceed the operating temperature range of the applied non-metallic parts as listed in the manuals of the pumps.

### **Table of Contents**

SECTION 1:	PUMP SPECIFICATIONS
SECTION 2:	<ul> <li>INSTALLATION &amp; OPERATION5</li> <li>Principle of Pump Operation</li> <li>Recommended Installation Guide</li> <li>Troubleshooting Guide</li> </ul>
SECTION 3:	• Composite Repair Parts Drawing • Composite Repair Parts List • Down Ported Option Drawing • Material Codes
SECTION 4:	• Air Distribution Valve Assembly • Pilot Valve Assembly
SECTION 5:	WET END14 • Diaphragm Servicing
SECTION 7:	WARRANTY & CERTIFICATES 15  • Warranty  • CE Deducation of Conformity Machinery

- CE Declaration of Conformity Machinery
- ATEX Declaration of Conformity

### **Explanation of Pump Nomenclature**



**Pump Series** 

**GH** Gas Duty - High Pressure

**Pump Size & Options** 

**2** 2

**Discharge Porting Position** 

T Top

**Diaphragm Check Valve Materials** 

**B** Nitrile

C FKM with PTFE

GB Nitrile Backup with PTFE Overlay and

PTFE Check Balls

**GN** Neoprene Backup with PTFE Overlay and PTFE Check Balls

V FKM (Stainless Wetted Only)

**Design Level** 

Construction

- I Cast Iron Wetted
- S Stainless

Your Serial #: (fill in from pump nameplate)

### **ATEX Detail**

ATEX Detail	Construction	Options
II 2 G Ex h IIC T5225°C (T2) Gb II 2 D Ex h IIIC T100°CT200°C Db	I,S	N/A



### Performance GH2 HIGH PRESSURE

#### SUCTION/DISCHARGE PORT SIZE

• GH2: 2" NPT

#### **CAPACITY**

• 0 to 74 gallons per minute (0 to 280 liters per minute)

#### AIR DISTRIBUTION VALVE

· No-lube, no-stall design

#### **SOLIDS-HANDLING**

• Up to .25" in. (6.5 mm)

#### **HEADS UP TO**

• 250 psi or 577 ft. of water (17 bar or 176 meters of water)

#### **MAXIMUM OPERATING PRESSURE**


• 125 psi (8.6 bar)

#### DISPLACEMENT/STROKE

• .36 Gallon / 1.3 liter

#### SHIPPING WEIGHT

- Cast Iron 172lbs. (78kg)
- · Stainless Steel 176 lbs. (80kg)



### **Materials**

Material Profile:		Operating Temperatures:	
CAUTION! Operating temperature limitations are as follows:	Max.	Min.	
Conductive Acetal: Tough, impact resistant, ductile. Good abrasion resistance and low friction surface. Generally inert, with good chemical resistance except for strong acids and oxidizing agents.	190°F 88°C	-20°F -29°C	
<b>EPDM:</b> Shows very good water and chemical resistance. Has poor resistance to oils and solvents, but is fair in ketones and alcohols.	280°F 138°C	-40°F -40°C	
FKM: (Fluorocarbon) Shows good resistance to a wide range of oils and solvents; especially all aliphatic, aromatic and halogenated hydrocarbons, acids, animal and vegetable oils. Hot water or hot aqueous solutions (over 70°F(21°C)) will attack FKM.	350°F 177°C	-40°F -40°C	
Hytrel®: Good on acids, bases, amines and glycols at room temperatures only.	220°F 104°C	-20°F -29°C	
Neoprene: All purpose. Resistance to vegetable oils. Generally not affected by moderate chemicals, fats, greases and many oils and solvents. Generally attacked by strong oxidizing acids, ketones, esters and nitro hydrocarbons and chlorinated aromatic hydrocarbons.	200°F 93°C	-10°F -23°C	
<b>Nitrile:</b> General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C	
<b>Nylon:</b> 6/6 High strength and toughness over a wide temperature range. Moderate to good resistance to fuels, oils and chemicals.	180°F 82°C	32°F 0°C	

Polypropylene: A thermoplastic polymer. Moderate tensile and flex strength. Resists stong acids and alkali. Attacked by chlorine, fuming nitric acid and other strong oxidizing agents.	180°F 82°C	32°F 0°C
<b>PVDF:</b> (Polyvinylidene Fluoride) A durable fluoroplastic with excellent chemical resistance. Excellent for UV applications. High tensile strength and impact resistance.	250°F 121°C	0°F -18°C
Santoprene®: Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	275°F 135°C	-40°F -40°C
<b>UHMW PE:</b> A thermoplastic that is highly resistant to a broad range of chemicals. Exhibits outstanding abrasion and impact resistance, along with environmental stress-cracking resistance.	180°F 82°C	-35°F -37°C
Urethane: Shows good resistance to abrasives. Has poor resistance to most solvents and oils.		32°F 0°C
Virgin PTFE: (PFA/TFE) Chemically inert, virtually impervious. Very few chemicals are known to chemically react with PTFE; molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	220°F 104°C	-35°F -37°C

Maximum and Minimum Temperatures are the limits for which these materials can be operated. Temperatures coupled with pressure affect the longevity of diaphragm pump components. Maximum life should not be expected at the extreme limits of the temperature ranges.

#### **Metals:**

Alloy C: Equal to ASTM494 CW-12M-1 specification for nickel and nickel alloy.


**Stainless Steel:** Equal to or exceeding ASTM specification A743 CF-8M for corrosion resistant iron chromium, iron chromium nickel and nickel based alloy castings for general applications. Commonly referred to as 316 Stainless Steel in the pump industry.


For specific applications, always consult the Chemical Resistance Chart.





### **Dimensional Drawings**

### **GH2, Cast Iron Wetted**Dimensions are ± .13" (3mm). Figures in parenthesis = millimeters













### **Dimensional Drawings**

**GH2, Stainless Wetted**Dimensions are ± .13" (3mm). Figures in parenthesis = millimeters









### **Principle of Pump Operation**

#### PRINCIPLE OF OPERATION

This pump is a 2:1 pressure ratio single acting pump powered by compressed gas. The 2:1 ratio is achieved by simultaneously applying gas pressure over a single end of each of two pistons connected in series by a shaft. The two pressurized ends are those most distant from the pumped fluid, with the force from the gas pressure exerted in the direction of the pumped fluid. The combined force is transferred through to the single end of the piston nearer to the pumped fluid—the single piston end having an area equal to one-half that of the two "gas" ends—and then through a fluid cell to a single pumping diaphragm.

On this single acting pump the suction stroke is independent of all discharge conditions and requires less gas pressure than the discharge stroke. The suction stroke is accomplished through a gas regulator which pressurizes the piston area in the rear cylinder adjacent to the intermediate bracket, while simultaneously exhausting the other two piston areas: one in the front cylinder, adjacent to the intermediate bracket, and the other behind the rear cylinder piston, adjacent to the cap end.

#### **OPERATION**

The regulator is factory preset to 30 psi. After the pump is installed and in operation, the operator should raise or lower the setting until maximum performance is determined by trial and error. A setting which is too high will result in excessively rapid and noisy operation, with a loss in performance and eventually shortened pump life. The hose assemblies deliver gas to the non-wetted portions of the pump, and care should be taken that they are neither crimped nor cut.

#### INSTALLATION PROCEDURES

Position the pump as close as possible to the source of the liquid to be pumped. Avoid long or undersize suction lines and use the minimum number of fittings. For permanent installation involving rigid piping, install short flexible sections of hose between the pump and piping. This reduces strains and permits easier removal of the pump for service when required.

#### **GAS SUPPLY**

Do not connect the unit to a gas supply in excess of 125 PSI (8.61 bars). Install a shutoff valve in the gas supply line to permit removal of the unit for servicing. When connecting an gas supply of rigid piping, mount a section of flexible line to the pump to eliminate piping strain. In permanent installations, an gas-line filter is recommended.

#### FREEZING OR ICING OF EXHAUST

Icing of the gas exhaust can occur under certain conditions of temperature and humidity on compressed gas power equipment. Icing is more likely to occur at high discharge pressures. Use of the Warren Rupp Air Dryer should eliminate the problem.

#### MAINTENANCE AFTER USE

When the pump is used for materials that tend to settle out or transform from liquid to solid form, care must be taken after each use or during idle time to remove them and flush the pump as required to prevent damage. In freezing temperatures the pump must be completely drained when idle. This model must be tilted to allow the liquid from the chambers to run out of the discharge port.



#### IMPORTANT

Read these safety warnings and instructions in this manual completely, before installation and startup of the pump. It is the responsibility of the

purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty



A CAUTION

Before pump operation, inspect all gasketed fasteners for looseness caused by gasket creep. Re-torque loose fasteners

to prevent leakage. Follow recommended torques stated in this manual.



WARNING

Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump.

The discharge line may be pressurized and must be bled of its pressure.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the

atmosphere. The air exhaust must be piped to an appropriate area for safe disposition.



WARNING

Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves,

containers or other miscellaneous equipment must be grounded.



SANDPIPERPUMP.COM

#### **CHECK VALVE SERVICING**

Need for inspection or service is usually indicated by poor priming, unstable cycling, reduced performance or the pump's cycling but not pumping.

#### DIAPHRAGM SERVICING/FILLING DRIVER FLUID

Motive power is delivered to the single diaphragm of the pump through a fluid cell located between the diaphragm and the drive piston. During preventative maintenance servicing (where the diaphragm has not ruptured, and the fluid cell is still filled), the fluid should be drained from the chamber by removing the pipe plug, in the lower most portion of inner chamber, item 54.

To fill the fluid cell, the piston(s) must be on full discharge stroke. To do this and hold during fill procedure, remove item 46, (fitting) from the cylinder cap (item 15) and insert gas pressure. This need not be more than 10 PSI. This will move the piston(s) and hold them in the discharge position. Remove the pipe plug at the top of the fluid chamber, and fill the chamber with ethylene glycol (anti-freeze). The chamber will take 3000 ml (101.5 fluid ounces) of fluid. If the diaphragm is PTFE, use 2800 ml (95 fluid ounces). Tilt the pump to evacuate air pockets from the fluid chamber. Abox wrench can be used to flex the diaphragm and purge air from the fluid chamber. Fill the chamber to the top of the fill hole, and re-insert the pipe plug, using thread compound.

If the glycol cell fluid is not compatible with the pumped product or would form a potentially dangerous mixture if the diaphragm ruptured, consult the factory before choosing an alternative fluid.

#### **CYLINDER PISTON SERVICING**

The driver fluid must be drained (see above) to service the cylinder piston. The piston seals are different on the natural gas side versus the driver fluid side. Typically, the fluid side will require replacement before the gas side. Remove the nuts and washers that secure the gas side piston cap and inner fluid chamber to the intermediate bracket. The cylinders may now be removed. Inspect the cylinder wall carefully. Scratches can cause driver fluid to leak to the gas side of the pump, which can find its way to the exhaust muffler. Scratches on the gas cylinder will cause too much gas to leak when on pressure stroke. The locknuts holding the cylinder to the rod can now be removed. Carefully inspect the piston for scratches, burrs and wear, especially if the piston seals are worn.

The piston seals can now be inspected or replaced. NATURAL GAS SIDE—The gas side piston has a T-Seal. If the seal is worn showing flat areas or gouges, it will require replacement. Remove seal and back-up (spacer). Remove wear rings and carefully inspect for wear. During reassembly make sure the ends of the back up spacer and wear ring end are <u>not</u> across from each other. WET SIDE—The wet side piston has a yellow PSP seal. Inspect for flat spots and gouges. Behind the seal is an energizer ring that helps to load the seal against the cylinder wall. (The energizer ring is included with the new seal.) The wear rings are the same as on the air side. Again, make sure the ends are not across from each other.

Reassembly of both pistons is the opposite of removal. Make sure the side of the **locknut with the seal is next to the piston.** The groove in the piston or o-ring (item 35), must be toward the pump center (o-ring seals next to the rod). Apply a heavy oil to the piston seals when sliding on the cylinder. The piston/nut should be torqued at 500 in./lbs. (56.49 Newton meters). The studs that secure the cylinders to the intermediate should be torqued at 250 in./lbs. (28.24 Newton meters). **IMPORTANT NOTE:** Reassembly of the wet side piston/seal assembly differs from the gas side in that it must be carefully pressed into the cylinder. An arbor press is commonly used for this purpose.

#### NATURAL GAS VALVE LUBRICATION

The SandPIPER pump's pilot valve and main gas valve assemblies are designed to operate WITHOUT lubrication. This is the preferred mode of operation. There may be instances of personal preference, or poor quality gas supplies when lubrication of the compressed natural gas supply is required. The pump gas system will operate with properly lubricated compressed gas supplies. Proper lubricatrion of the compressed gas supply would entail the use of a natural gas line lubricator set to deliver one drop of 10 wt., non-detergent oil for every 20 SCFM of gas the pump consumed at its point of operation. Consult the pump's published



#### **A** WARNING

Do not smoke near the pump or use the pump near an open flame. Fire or explosion could result.



#### **WARNING**

This pump must not be used for fluid transfer into aircraft.



#### **WARNING**

This pump is pressurized internally with natural gas pressure during operation. Always make certain that all

bolting is in good condition and that all of the correct bolting is reinstalled during assembly.



#### **A WARNING**

When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



#### **WARNING**

Before doing any maintenance on the pump, be certain all pressure is completely vented from the pump, suction, discharge,

piping, and all other openings and connections. Be certain the natural gas supply is locked out or made non-operational, so that it cannot be started while work is being done on the pump. Be certain that approved eye protection and protective clothing are worn all times in the vicinity of the pump. Failure to follow these recommendations may result in serious injury or death.



#### **A** WARNING

Airborne particles and loud noise hazards. Wear ear and eye protection.

Pump complies with EN809 Pumping Directive, Directive 98/37/EC Safety of Machinery.



performance curve to determine this.

It is important to remember to inspect the sleeve and spool set routinely. It should move back and forth freely. This is most important when the gas supply is lubricated. If a lubricator is used, oil accumulation will, over time, collect any debris from the compressed gas. This can prevent the pump from operating properly. Water in the compressed gas supply can create problems such as icing or freezing of the exhaust gas causing the pump to cycle erratically, or stop operating. This can be addressed by using a point of use dryer to supplement a plant's gas drying equipment. This device will remove excess water from the compressed gas supply and alleviate the icing or freezing problem.

#### **ESGDS: Externally Serviceable Gas Distribution System**

Please refer to the exploded view drawing and parts list in the Service Manual supplied with your pump. If you need replacement or additional copies, contact your local Warren Rupp Distributor, or the Warren Rupp factory Literature Department. To receive the correct manual, you must specify the MODEL and TYPE information found on the name plate of the pump.

#### **Main Natural Gas Valve**

The main natural gas valve sleeve and spool set is located in the valve body mounted on the pump with four hex head capscrews. The valve body assembly is removed from the pump by removing these four hex head capscrews.

With the valve body assembly off the pump, access to the sleeve and spool set is made by removing four hex head capscrews (each end) on the end caps of the valve body assembly. With the end caps removed, slide the spool back and forth in the sleeve. The spool is closely sized to the sleeve and must move freely to allow for proper pump operation. An accumulation of oil, dirt or other contaminants from the pump's gas supply, or from a failed diaphragm, may prevent the spool from moving freely. This can cause the spool to stick in a position that prevents the pump from operating. If this is the case, the sleeve and spool set should be removed from the valve body for cleaning and further inspection. Remove the spool from the sleeve. Using an arbor press or bench vise (with an improvised mandrel), press the sleeve from the valve body. Take care not to damage the sleeve. At this point, inspect the o-rings on the sleeve for nicks, tears or abrasions. Damage of this sort could happen during assembly or servicing. A sheared or cut o-ring can allow the pump's compressed gas supply to leak or bypass within the valve assembly, causing the pump to leak compressed gas from the pump exhaust or not cycle properly. This is most noticeable at pump dead head or high discharge pressure conditions. Replace any of these o-rings as required or set up a routine, preventive maintenance schedule to do so on a regular basis. This practice should include cleaning the spool and sleeve components with a safety solvent or equivalent, inspecting for signs of wear or damage, and replacing worn components. To re-install the sleeve and spool set, lightly lubricate the o-rings on the sleeve with an o-ring assembly lubricant or lightweight oil (such as 10 wt. gas line lubricant). Press the set into the valve body easily, without shearing the o-rings. Re-install one end cap, gasket and bumper on the valve body. Using the arbor press or bench vise that was used in disassembly, press the sleeve back into the valve body. You may have to clean the surfaces of the valve body where the end caps mount. Material may remain from the old gasket. Old material not cleaned from this area may cause air leakage after reassembly. Take care that the bumper stays in place allowing the sleeve to press in all the way. Reinstall the spool, the opposite end cap, gasket and bumper on the valve body. After inspecting and cleaning the gasket surfaces on the valve body and intermediate, reinstall the valve body on the pump using new gaskets. Tighten the four hex head capscrews evenly and in an alternating cross pattern.

#### PILOT VALVE ACTUATOR SERVICING

The bushings for the pilot valve actuators are threaded into the intermediate bracket from the outside. The plunger may be removed for inspection or

replacement from the inside by removing the natural gas distribution valve body and the pilot valve body from the pump. The plungers should be visible as you look into the intermediate from the top. Depending on their position, you may find it necessary to use a fine piece of wire to pull them out.

Under rare circumstances, it may become necessary to replace the o-ring seal. The bushing can be pushed through the inner chamber by removing the outer chamber the assembly to reach the bushing.

### **Troubleshooting Guide**

#### TROUBLE SHOOTING

#### Pump will not cycle

- A. Check to make sure the unit has enough pressure to operate and that the gas inlet valve is open.
- B. Check the discharge line to insure that the discharge line is neither closed nor blocked.
- C. If the spool in the gas distribution valve is not shifting check the main spool. It must slide freely.
- Excessive gas leakage in the pump can prevent cycling. Gas leakage from the exhaust port indicates leakage in the gas distribution valve. See further service instructions.
- E. Blockage in the liquid chamber can impede movement of diaphragm.

#### 2. Pump cycles but will not pump

- A. Suction side of pump pulling in gas. Check the suction line for air leaks and be sure that the end of the suction line is submerged. Check flange bolting. Check valve flanges and manifolds to chamber flange joints.
- B. Make certain the suction line or strainer is not plugged. Restriction at the suction is indicated by a high vacuum reading when a vacuum gauge is installed in the suction line.
- C. Check valves may not be seating properly. To check, remove the suction line and cover the suction port with your hand. If the unit does not pull a good suction (vacuum), the check valves should be inspected for proper seating.
- D. Static suction life may be too high. Priming can be improved by elevating the suction and discharge lines higher than the check valves and pouring liquid into the unit through the suction inlet. When priming at high suction lifts or with long suction lines operate the pump at maximum cycle rate.


#### 3. Low performance

- A. Capacity is reduced as the discharge pressure increases. Performance capability varies with available inlet supply. Check air pressure at the pump inlet when the pump is operating to make certain that adequate gas supply is maintained.
- B. Check vacuum at the pump suction. Capacity is reduced as vacuum increases. Reduced flow rate due to starved suction will be evident when cycle rate can be varied without change in capacity. This condition will be more prevalent when pumping viscous liquids. When pumping thick, heavy material the suction line must be kept as large in diameter and as short as possible, to keep suction loss minimal.
- C. Low flow rate and slow cycling rate indicate restricted flow through the discharge line. Low flow rate and fast cycling rate indicate restriction in the suction line or air leakage into suction. For more information, refer to the Warren Rupp Troubleshooting Guide.

WARRANTY: This unit is guaranteed for a period of five years against defective material and workmanship.



### **Composite Repair Parts Drawing-Cast Iron**



### Service & Repair Kits-Cast Iron Wetted

476.242.000 Air End Kit

Sleeve and Spool Set, O-rings, Bumpers, U-Cup Seals,

and Gaskets, and pilot valve assembly

476.048.360 Wet End Kit

Buna diaphragm, Buna check balls, Buna o-rings and

carbon steel seats

476.048.633 Wet End Kit

FKM diaphragm, FKM check balls, PTFE o-rings and

carbon steel seats

476.048.649 Wet End Kit

Buna Backup Diaphragm, PTFE Overlay Diaphragm

and O-Rings, Carbon Steel Seats



### **Composite Repair Parts List-Cast Iron Wetted**

mposi	te kepair Parts	LIS
Part Number	Description	Qty.
008.130.080	Adapter	1
020.054.000	Gauge, Pressure (Included with item #3)	1
020.056.000	Regulator (Includes Item #2)	1
031.012.000	Sleeve and Spool Set	1
050.005.360 W	Ball, Check - Buna (Cast Iron Wetted)	2
050.005.363 W		2
050.010.600	Ball, Check - PTFE (Cast Iron Wetted)	2
070.006.571	Bearing, Sleeve (Included with item #9)	2
095.040.156	Body, Valve	1
095.115.001	Pilot Valve Assy	1
114.027.010	Intermediate (Includes item #6)	1
115.064.080	Bracket, Mounting	1
115.067.080	Bracket, Mounting	1
115.164.000	Bracket, Mounting Gas Regulator	1
132.002.360	Bumper, Diaphragm	2
132.014.358	Bumper, Air Valve	2
135.016.506	Bushing, Threaded	2
165.011.157	Cap, End	2
165.047.010	Cap, Cylinder	1
170.024.330	Capscrew, Hex-Hd 7/16-14 x 1	2
170.032.330	Capscrew, Hx-Hd 1/4-20 x 3/4	8
170.045.330	Capscrew, Hx-Hd 5/16-18 x 1.25	4
170.050.330	Capscrew, Hx-Hd 1/4-20 x 1/2	2
170.052.330	Capscrew, Hx-Hd 3/8-16 x 2.25	6
170.057.330	Capscrew, Hx-Hd 5/16-18 X .75	6
170.060.330	Capscrew, Hx-Hd 7/16-14 x 2.00	8
196.029.015	Chamber, Inner (Includes item #46)	1
196.053.010		1
275.009.331		2
		1
		1
		1
		1
		1
	,	1
		2
		1
		1
		2
		1
		18
		2
	•	2
	•	6
	-	5
	•	2
		4
	,	4
		2
	. ,	2
		1
020.011.114	Plunger, Actuator	2
	Part Number  008.130.080 020.054.000 020.056.000 031.012.000 050.005.360 W 050.005.363 W 050.010.600 070.006.571 095.040.156 095.115.001 114.027.010 115.064.080 115.164.000 132.002.360 132.014.358 135.016.506 165.011.157 165.047.010 170.024.330 170.032.330 170.045.330 170.050.330 170.057.330 170.060.330 196.029.015 196.053.010	008.130.080         Adapter           020.054.000         Gauge, Pressure (Included with item #3)           020.056.000         Regulator (Includes Item #2)           031.012.000         Sleeve and Spool Set           050.005.363 W         Ball, Check - Buna (Cast Iron Wetted)           050.005.363 W         Ball, Check - FKM (Cast Iron Wetted)           050.010.600         Ball, Check - PTFE (Cast Iron Wetted)           070.006.571         Bearing, Sleeve (Included with item #9)           095.040.156         Body, Valve           095.115.001         Pilot Valve Assy           114.027.010         Intermediate (Includes item #6)           115.064.080         Bracket, Mounting           115.067.080         Bracket, Mounting           115.067.080         Bracket, Mounting           115.067.080         Bracket, Mounting           115.067.080         Bumper, Air Valve           132.002.360         Bumper, Air Valve           135.016.506         Bushing, Threaded           165.047.010         Cap, Cylinder           170.024.330         Capscrew, Hex-Hd 7/16-14 x 1           170.052.330         Capscrew, Hx-Hd 5/16-18 x 1.25           170.057.330         Capscrew, Hx-Hd 5/16-18 x 2.25           170.060.330         Capscrew, Hx-Hd 5

49	677.001.542	Ring, Wear	4
50	685.043.120	Rod, Connecting	1
<b>(51)</b>	720.004.377	Seal, U-Cup HNBR	2
52	720.022.360	Seal, T Assembly with Backup Rings	1
53	720.034.000	Seal, PSP Assembly with Energizer Ring	1
54	722.042.080	Seat, Check Valve (Cast Iron Wetted)	2
55	807.047.080	Stud	8
56	866.073.330	Connector, Male	2
57	866.074.330	Fitting, Male 90° Elbow	2
58	866.075.330	Fitting, Male 90° Elbow	1
59	866.076.330	Fitting, Male 90° Elbow	1
60	900.001.330	Washer, Lock 1/4"	2
61	900.003.330	Washer, Lock 1/2"	4
62	900.004.330	Washer, Lock 5/16"	6
63	900.006.330	Washer, Lock 7/16" (Stainless Wetted)	20
64	920.025.000	Strap, Ground	1
	E Diaphragm <i>A</i>	•	
63	286.005.360	Diaphragm, Buna	1
64	286.020.604	Diaphragm, Overlay	1
65	545.008.330	Nut, Hex 5/8-11	1
66	612.039.010	Plate, Outer Diaphragm (Includes stud)	1

Plate, Inner Diaphragm

Washer, Lock 5/8"

612.047.330

900.007.330

68

#### **LEGEND:**

= Items contained within Air End Kits


= Items contianed within Wet End Kits

Note: Kits contain components specific to the material codes.



<sup>\*</sup> Air End Kit only includes sleeve and spool set, not entire air valve assembly

### **Composite Repair Parts Drawing-Stainless**



476.242.000 Air End Kit

Sleeve and Spool Set, O-rings, Bumpers, U-Cup Seals,

and Gaskets, and pilot valve assembly

476.056.360

Buna diaphragm, Buna check balls, Buna o-rings and

stainless steel seats

476.056.633 Wet End Kit

FKM diaphragm, FKM check balls, PTFE o-rings and

carbon steel seats

476.056.649 Wet End Kit

Buna backup diaphragm, PTFE Overlay, PTFE check balls, PTFE seals and stainless steel seats



### **Composite Repair Parts List-Stainless**

	ılıboəi	te Kepaii Parts	FI2
<u>Item</u>	Part Number	Description	Qty.
1	008.013.080	Adapter	1
2	020.054.000	Gauge, Pressure (Included with item #3)	1
3	020.056.000	Regulator (Includes Item #2)	1
<u>4</u>	031.012.000	Sleeve and Spool Set	1
5	050.018.600	Ball, Check - PTFE (Stainless Wetted)	2
6	070.006.571	Bearing, Sleeve (Included with item #9)	2
7	095.040.156	Body, Valve	1
8	095.115.001	Pilot Valve Assy	1
9	114.027.010	Intermediate (Includes item #6)	1
10	115.067.080	Bracket, Mounting	1
11	115.172.000	Bracket, Mounting (Stainless Wetted)	1
12	115.164.000	Bracket, Mounting Gas Regulator	1
13	132.002.360	Bumper, Diaphragm	2
4	132.014.358	Bumper, Air Valve	2
<b>(</b> 5)	135.016.506	Bushing, Threaded	2
16	165.011.157	Cap, End	2
17	165.047.010	Cap, Cylinder	1
18	170.024.330	Capscrew, Hx-Hd 7/16-14 x 1	4
19	170.032.330	Capscrew, Hx-Hd 1/4-20 x 3/4	8
20	170.045.330	Capscrew, Hx-Hd 5/16-18 x 1.25	4
21	170.043.330	Capscrew, Hx-Hd 1/4-20 x 1/2	2
22	170.050.330	Capscrew, Hx-Hd 5/16-18 X .75	6
23	170.060.330	Capscrew, Hx-Hd 7/16-14 x 2.00	8
24	170.066.330	Capscrew, Hx-Hd 1/2-13 x 2.25	4
25	196.029.015		1
25 26		Chamber, Inner (Includes item #49)	1
	196.047.010	Chamber, Outer (Includes item #48)	2
27	275.009.331	Cylinder	1
28	286.036.360	Diaphragm - Buna	1
20	286.036.363	Diaphragm - FKM	
29	312.046.110	Elbow, 90° Street (Stainless Wetted)	1 1
30	326.003.080	Foot, Mounting	1
31	326.006.080	Floors Disabarra (Chairless Wethod)	
32	334.043.110	Flange, Discharge (Stainless Wetted)	1
33	334.044.110	Flange, Suction (Stainless Wetted)	1
34	360.010.360	Gasket, End Cap	2
<u>35</u>	360.041.379	Gasket, Air Valve	1
<u>36</u>	360.048.360	Gasket, Air Valve	1
37	426.047.000 F	Hose, Assembly	2
38	426.048.000 F	Hose, Assembly	1
39	545.007.330	Nut, Hex 7/16-14 (Stainless Wetted)	20
40	545.008.330	Nut, Hex 1/2-13 (Stainless Wetted)	4
41	547.009.080	Nut, Sealing	2
42	560.001.360	O-ring	2
43)	560.020.360	O-ring	6
44	560.022.360	O-ring	5
45	560.076.360	O-ring	2
46	560.106.360	O-ring - Buna (Stainless Wetted)	4
	560.106.363	O-ring - FKM (Stainless Wetted)	4
	720.060.608	Seal - PTFE (Stainless Wetted)	4
47	605.012.151	Piston	2
48	618.003.110	Plug, NPT 1/4" (Included with item #26)	2
49	618.003.330	Plug, NPT 1/4" (Included with item #25)	2
50	618.007.330	Plug, NPT 1"	1 I

<b>(51)</b>	620.011.114	Plunger, Actuator	2
52	677.001.542	Ring, Wear	4
53	685.043.120	Rod, Connecting	1
<u>54</u>	720.004.377	Seal, U-Cup HNBR	2
55	720.022.360	Seal, T Assembly with Backup Rings	1
56	720.034.000	Seal, PSP Assembly with Energizer Ring	1
57	722.040.110	Seat, Check Valve (Stainless Wetted)	2
58	807.047.080	Stud	8
59	866.073.330	Connector, Male	2
60	866.074.330	Fitting, Male 90° Elbow	2
61	866.075.330	Fitting, Male 90° Elbow	1
62	866.076.330	Fitting, Male 90° Elbow	1
63	900.001.330	Washer, Lock 1/4"	2
64	900.003.330	Washer, Lock 1/2"	4
65	900.004.330	Washer, Lock 5/16"	6
66	900.006.330	Washer, Lock 7/16" (Stainless Wetted)	20
67	920.025.000	Strap, Ground	1
PTFF	Diaphragm Assen	nbly	
68	286.005.360	Diaphragm, Buna	1
[00]	286.005.363	Diaphragm, FKM	1
69	286.020.604	Diaphragm, Overlay	1
70	545.009.330	Nut, Hex 5/8-11	1
71	612.097.110	Plate, Outer Diaphragm (Includes stud)	1
72	612.047.330	Plate, Inner Diaphragm	1
73	900.007.330	Washer, Lock 5/8"	1

#### **LEGEND:**

= Items contained within Air End Kits

= Items contianed within Wet End Kits

**Note:** Kits contain components specific to the material codes.



<sup>\*</sup> Air End Kit only includes sleeve and spool set, not entire air valve assembly

### Material Codes - The Last 3 Digits of Part Number

- 000.....Assembly, sub-assembly; and some purchased items
- 010.....Cast Iron
- 015.....Ductile Iron
- 020.....Ferritic Malleable Iron
- 080.....Carbon Steel, AISI B-1112
- 110.....Alloy Type 316 Stainless Steel
- 111 .....Alloy Type 316 Stainless Steel (Electro Polished)
- 112.....Alloy C
- 113.....Alloy Type 316 Stainless Steel (Hand Polished)
- 114.....303 Stainless Steel
- 115.....302/304 Stainless Steel
- 117.....440-C Stainless Steel (Martensitic)
- 120.....416 Stainless Steel (Wrought Martensitic)
- 148..... Hardcoat Anodized Aluminum
- 150.....6061-T6 Aluminum
- 152.....2024-T4 Aluminum (2023-T351)
- 155.....356-T6 Aluminum
- 156.....356-T6 Aluminum
- 157.....Die Cast Aluminum Alloy #380
- 158.....Aluminum Alloy SR-319
- 162.....Brass, Yellow, Screw Machine Stock
- 165.....Cast Bronze, 85-5-5-5
- 166.....Bronze, SAE 660
- 170.....Bronze, Bearing Type, Oil Impregnated
- 180.....Copper Alloy
- 305.....Carbon Steel, Black Epoxy Coated
- 306.....Carbon Steel, Black PTFE Coated
- 307.....Aluminum, Black Epoxy Coated
- 308..... Stainless Steel, Black PTFE Coated
- 309.....Aluminum, Black PTFE Coated
- 313.....Aluminum, White Epoxy Coated
- 330.....Zinc Plated Steel
- 332.....Aluminum, Electroless Nickel Plated
- 333.....Carbon Steel, Electroless
- Nickel Plated 335.....Galvanized Steel
- 337.....Silver Plated Steel
- 351.....Food Grade Santoprene®
- 353.....Geolast; Color: Black
- 354.....Injection Molded #203-40
- Santoprene® Duro 40D +/-5; Color: RED
- 356.....Hytrel®
- 357..... Injection Molded Polyurethane
- 358.....Urethane Rubber (Some Applications) (Compression Mold)
- 359.....Urethane Rubber
- 360.....Nitrile Rubber Color coded: RED
- 363.....FKM (Fluorocarbon)
  Color coded: YELLOW

- 364.....EPDM Rubber
  - Color coded: BLUE
- 365.....Neoprene Rubber
  - Color coded: GREEN
- 366.....Food Grade Nitrile
- 368.....Food Grade EPDM
- 371.....Philthane (Tuftane)
- 374.....Carboxylated Nitrile
- 375.....Fluorinated Nitrile
- 378.....High Density Polypropylene
- 379.....Conductive Nitrile
- 408.....Cork and Neoprene
- 425.....Compressed Fibre
- 426.....Blue Gard
- 440.....Vegetable Fibre
- 500.....Delrin® 500
- 502.....Conductive Acetal, ESD-800
- 503.....Conductive Acetal, Glass-Filled
- 506.....Delrin® 150
- 520.....Injection Molded PVDF Natural color
- 540.....Nylon
- 542.....Nylon
- 544.....Nylon Injection Molded
- 550.....Polyethylene
- 551.....Glass Filled Polypropylene
- 552.....Unfilled Polypropylene
- 555.....Polyvinyl Chloride
- 556.....Black Vinyl
- 558.....Conductive HDPE
- 570.....Rulon II®
- 580.....Ryton®
- 600.....PTFE (virgin material)
  Tetrafluorocarbon (TFE)
- 603.....Blue Gylon®
- 604.....PTFE
- 606.....PTFE
- 607.....Envelon
- 608.....Conductive PTFE
- 610.....PTFE Encapsulated Silicon
- 611.....PTFE Encapsulated FKM
- 632.....Neoprene/Hytrel®
- 633.....FKM/PTFE
- 634.....EPDM/PTFE
- 635.....Neoprene/PTFE
- 637.....PTFE, FKM/PTFE
- 638.....PTFE, Hytrel®/PTFE
- 639.....Nitrile/TFE
- 643.....Santoprene®/EPDM
- 644.....Santoprene®/PTFE
- 656.....Santoprene® Diaphragm and Check Balls/EPDM Seats
- 661.....EPDM/Santoprene®
- 666.....FDA Nitrile Diaphragm,
- PTFE Overlay, Balls, and Seals 668.....PTFE, FDA Santoprene®/PTFE

- Delrin and Hytrel are registered tradenames of E.I. DuPont.
- Nylatron is a registered tradename of Polymer Corp.
- Gylon is a registered tradename of Garlock, Inc.
- Santoprene is a registered tradename of Exxon Mobil Corp.
- Rulon II is a registered tradename of Dixion Industries Corp.
- Ryton is a registered tradename of Phillips Chemical Co.
- Valox is a registered tradename of General Electric Co.

### **RECYCLING**

Warren Rupp is an ISO14001 registered company and is committed to minimizing the impact our products have on the environment. Many components of SANDPIPER® AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed. Pump users that recycle will gain the satisfaction to know that their discarded part(s) or pump will not end up in a landfill. The recyclability of SANDPIPER products is a vital part of Warren Rupp's commitment to environmental stewardship.



### 5 - YEAR Limited Product Warranty

Warren Rupp, Inc. ("Warren Rupp") warrants to the original end-use purchaser that no product sold by Warren Rupp that bears a Warren Rupp brand shall fail under normal use and service due to a defect in material or workmanship within five years from the date of shipment from Warren Rupp's factory. Warren Rupp brands include Warren Rupp®,SANDPIPER®, SANDPIPER Signature Series™, MARATHON®, Porta-Pump®, SludgeMaster™ and Tranquilizer®.

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

~ See sandpiperpump.com/content/warranty-certifications for complete warranty, including terms and conditions, limitations and exclusions. ~



Manufacturer: Warren Rupp, Inc. 800 N. Main Street Mansfield, Ohio, 44902 USA

Certifies that Air-Operated Double Diaphragm Pump Models: DSB Series, DMF Series, G Series, HDB Series, HDF Series, HP Series, F Series, MS Series, S Series, SL Series, SP Series, SSB Series, T Series, U1F Series, WR Series; High Pressure Pump Models: EH Series, GH Series, SH Series; Submersible Pump Models: SMA3 Series, SPA Series; and Surge Dampener/ Suppressor Models: DA Series, TA Series comply with the European Community Directive 2006/42/EC on Machinery, according to Annex VIII. This product has used Harmonized Standard EN809:2012, Pumps and Pump Units for Liquids - Common Safety Requirements, to verify conformance.

October 3, 2022

DATE/APPROVAL/TITLE:

Technical File on record with: DEKRA Certification B.V. Meander 1051 6825 MJ Arnhem The Netherlands Signature of authorized person

Dennis Hall

Printed name of authorized person

**Engineering Manager** 

Title





# SANDPIPER® EC Declaration of Conformity

Manufacturer: Warren Rupp, Inc. 800 N. Main Street Mansfield, Ohio, 44902 USA

Certifies that Air-Operated Double Diaphragm Pump Models: DSB Series, DMF Series, G Series, HDB Series, HDF Series, HP Series, F Series, MS Series, S Series, SL Series, SP Series, SSB Series, T Series, U1F Series, WR Series; High Pressure Pump Models: EH Series, GH Series, SH Series; Submersible Pump Models: SMA3 Series, SPA Series; and Surge Dampener/ Suppressor Models: DA Series, TA Series comply with the United Kingdom Statutory Instruments 2008 No. 1597, The Supply of Machinery (Safety) Regulations 2008, according to Annex VIII. This product has used Designated Standard EN809:2012, Pumps and Pump Units for Liquids - Common Safety Requirements, to verify conformance.

October 17, 2022

DATE/APPROVAL/TITLE:

Technical File on record with: DEKRA Certification UK Limited Stokenchurch House Oxford Road Stokenchurch HP14 3SX Signature of authorized person

Dennis Hall

Printed name of authorized person

**Engineering Manager** 

Title









### ATEX



### **EU Declaration of Conformity**

#### Manufacturer:

Warren Rupp, Inc.
A Unit of IDEX Corporation
800 North Main Street
Mansfield, OH 44902 USA

This declaration of conformity is issued under the sole responsibility of the manufacturer. Warren Rupp, Inc. declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of Directive **2014/34/EU** and applicable harmonized standards.

Harmonized Standards:

EN ISO 80079-36: 2016

EN ISO 80079-37: 2016

EN 60079-25: 2010

1. AODD Pumps and Surge Suppressors - Technical File on record with DEKRA Certification B.V.

Meander 1051 6825 MJ Arnhem The Netherlands

**Hazardous Location Applied:** 



II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metallic pump models with external aluminum components (DMF Series, EH Series, F Series, G & GH Series, HDB Series, HDF Series, MS Series, S Series, SH Series, SL Series, SPB Series, ST Series, T Series, and U1F Series)
- Conductive plastic pump models with integral muffler (PB1/4 Series, S Series, SL Series, SPE Series)
- Tranquilizer® surge suppressors (TA Series)



II 2 G Ex h IIB T5...225°C (T2) Gb II 2 D Ex h IIIB T100°C...T200°C Db

- ST Series with sight tubes (VL) and HP Series because of the projected area of non-conductive external components
- 2. AODD Pumps EU Type Examination Certificate No.: DEKRA 18ATEX0094X DEKRA Certification B.V. (0344)

Hazardous Location Applied:

6825 MJ Arnhem The Netherlands

Meander 1051



IM1 Ex h I Ma

II 1 G Ex h IIC T5...225°C (T2) Ga

II 1 D Ex h IIIC T100°C...T200°C Da

- Metallic pump models with no external aluminum (HDB Series, HDF Series, G Series, S Series, SPB Series)
- Conductive plastic pumps equipped with conductive muffler (S Series, SPE Series)

 $\langle x3 \rangle$ 

II 2 G Ex h ia IIC T5 Gb

II 2 D Ex h ia IIIC T100°C Db

• Pump models with ATEX rated pulse output kit option (HDB Series, HDF Series, PB1/4, S Series, SB Series)



II 2 G Ex h mb IIC T5 Gb

II 2 D Ex h mb tb IIIC T100° Db

- Pump model series S05, S1F, S15, S20, S30 equipped with ATEX rated integral solenoid option
- See "ATEX Details" page in user's manual for more information
- > See "Safety Information" page for conditions of safe use

DATE/APPROVAL/TITLE:

9 NOV 2023

Dennis Hall

**Engineering Manager** 



### **UKEx**



### **EU Declaration of Conformity**

#### Manufacturer:

Warren Rupp, Inc. A Unit of IDEX Corporation 800 North Main Street Mansfield, OH 44902 USA

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Warren Rupp, Inc declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of United Kingdom Statutory Instruments 2016 No. 1107 and all the applicable standards.

Designated Standards:

EN ISO 80079-36: 2016

EN ISO 80079-37: 2016

• EN 60079-25: 2010

1. AODD Pumps and Surge Suppressors - Technical File on record with: DEKRA Certification UK Limited

Stokenchurch House Oxford Road Stokenchurch HP14 3SX

**Hazardous Location Applied:** 

 $\langle x3 \rangle$ 

II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metallic pump models with external aluminum components (DMF Series, EH Series, F Series, G & GH Series, HDB Series, HDF Series, MS Series, S Series, SH Series, SL Series, SPB Series, ST Series, T Series, and U1F Series)
- Conductive plastic pump models with integral muffler (PB1/4 Series, S Series, SL Series, SPE Series)
- Tranquilizer® surge suppressors (TA Series)



II 2 G Ex h IIB T5...225°C (T2) Gb II 2 D Ex h IIIB T100°C...T200°C Db

• ST Series with sight tubes (VL) and HP Series because of the projected area of non-conductive external components

See "ATEX Details" page in user's manual for more information

See "Safety Information" page for conditions of safe use

DATE/APPROVAL/TITLE: 9 NOV 2023

Dennis Hall Engineering Manager